




# Leapfrog LeapPad 3 Battery Replacement

If the battery inside your LeapPad 3 is dead, it may need to be replaced.

Written By: Matt Irvine



## INTRODUCTION

To replace the battery you will need a replacement. Once you have the battery, following this guide will lead you to a fully functioning device.


---



### TOOLS:



- [iFixit Opening Tools](#) (1)
  - [Phillips #0 Screwdriver](#) (1)
  - [Anti-Static Wrist Strap](#) (1)
-

## Step 1 — Battery



- Before taking apart your device, ensure that it is turned off and that your anti-static wrist strap is secured to a ground.
  - Remove the six 10.0 mm Phillips #0 screws from the outer case and remove the cover with your hands.
- i** You will not need to pry the case off.


## Step 2



- Unplug the battery from the motherboard with your hands.
- i** The battery sits to the right of the motherboard.



## Step 3



- Pry the battery gently off of the plastic platform with an opening tool.

⚠ Do not to puncture the battery, as the material inside can be dangerous.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 07:20:40 PM.